

## **Home Master® Mini Filter Change Instructions**

Items Required: Replacement filter, paper towels, dish soap, unscented bleach

1. Clean & dry countertop area.
  2. Wash hands with soap and warm water, and dry.
  3. Close water supply to Home Master® Mini.
  4. Take care not to apply pressure to elbow fittings at base, while loosening filter counter-clockwise; then discard used filter cartridge.
  5. Clean base with dilute unscented bleach, rinse with water, and dry with paper towels.
  6. Unwrap the replacement filter and **remove the yellow plug** (if present) from its threaded end.
  7. Fit new filter cartridge into the base and tighten hand-tight.
  8. Use diverter valve lever to switch between filtered and unfiltered water.
  9. Open cold water supply to Mini and flush with cold water 5 minutes. **Initial discharge may be discolored.**
- NOTE: Do not filter hot water through your Home Master® Mini.**
10. Check for leaks.

Friendly Support: 1-877-693-7873  
[Support@ThePerfectWater.com](mailto:Support@ThePerfectWater.com)

*Perfect Water Technologies*

## **Home Master® Mini Filter Change Instructions**



Friendly Support: 1-877-693-7873  
[Support@ThePerfectWater.com](mailto:Support@ThePerfectWater.com)